

INSTRUCTIONS FOR USE

GRAVITY DATE


CALIBRE ADD14

Thank you for buying an Armin Strom watch.

Developed and manufactured in-house, the ADD14 calibre of your watch is a self-winding mechanical movement. Its micro-rotor is located in an inventive position on the dial side.

In addition to hours and minutes, your watch indicates seconds, the date, and day / night on three coaxial hands at 9 o'clock.

To guarantee the perfect working of your watch for many years to come, please pay careful attention to the recommendations for use set out in these instructions.



ARMIN STROM

SWISS WATCH MANUFACTURE

WINDING

Your watch is equipped with a self-winding mechanical movement. Your wrist movements enable to stock the energy necessary for its operation. When fully wound, it has a minimum power-reserve of five days.

If it stops for a longer resting period than its power-reserve, wind it manually. To do so, turn the crown clockwise in position 1 (at least ten times).



ARMIN STROM

SWISS WATCH MANUFACTURE

SETTING THE TIME

Pull the crown out to position 2. Adjust the hours and minutes by turning the crown forwards or backwards.

Make sure that the day / night indication displays the right period of the 24-hour period.

Important: Always push the crown back to position 1 once the settings have been made.




ARMIN STROM

SWISS WATCH MANUFACTURE

SETTING THE DATE

Important: Never correct the date between 10 p.m. and 2 a.m.

The date may be adjusted by pressing the corrector located on the side of the case using the corrector tool provided with your watch. Each time it is pressed, the date display moves forward one day.



ARMIN STROM

SWISS WATCH MANUFACTURE

ARMIN STROM AG

Bözingenstrasse 46
CH-2502 Biel/Bienne
Switzerland
Tel. +41 (0) 32 343 33 44
Fax +41 (0) 32 343 33 40

info@arminstrom.com

WWW.ARMINSTROM.COM

Facebook: www.facebook.com/arminstrom

Twitter: www.twitter.com/arminstrom

Instagram: www.instagram.com/arminstrom



ARMIN STROM

SWISS WATCH MANUFACTURE